


Driver installation for GG-D1200CW Printer


(USB connection method)

I . Install printer driver


Connect the printer to PC with USB cable, and the power of the printer is ready.
Choose the right language, click OK.




Follow the tips and turn on the printer power switch.



Click Install



The printer driver installation is complete and click OK



Click finish

